

VISIONSENSOR DATAVS2 PRO

DATAVS2-06REPRO

Vision Sensor 6 mm lins PRO

- 360° mönsterigenkänning
- Kontroller för Streckkod, Datamatrix och OCV
- 20 olika inspektioner
- 3 utgångar
- RS232 gränssnitt



PRODUKTBESKRIVNING

DataVS2 är en serie Visionsensorer för flexibla lösningar för maskin applikationer.

Sensorn är komplett med optik, röd LED-belysning och elektronik i ett kompakt hus. Parametrarna i sensorn sätts via PC genom Ethernet-kommunikation.

Mjukvaran bifogas med sensorn och är utvecklad för att leda användaren steg för steg genom parameter sättningen. DataVS2 är tillgänglig i 4 olika versioner med olika kontrollverktyg.


PRO modellen - klarar de funktioner som finns i Advanced och ID modellerna.

Den klarar 360° mönsterigenkänning och även streckkod, datamatrix och OCV. Den har även 5 nya verktyg: 3 locators (Streckkod, Datamatrix och 360° konturmatchning)

2 kontroller: 360° kontur räknare, 360° defect finder



KONTROLLVERKTYG



LÄSFÄLT

Läsfält

Arbetsavstånd(mm)

Läsfält (Bredd x Höjd) i mm


DATAVS2-16-DE-xxx

DATAVS2-12-DE-xxx


DATAVS2-08-DE-xxx

DATAVS2-06-DE-xxx

50	-	17 x 12	25 x 20	42 x 30
80	-	25 x 20	40 x 30	60 x 41
110	-	33 x 25	55 x 40	80 x 55
140	31 x 24	45 x 35	70 x 50	98 x 69
170	39 x 29	53 x 38	85 x 60	118 x 83
200	46 x 34	60 x 50	100 x 70	138 x 92
300	70 x 53	90 x 65	145 x 103	201 x 140
400	94 x 71	121 x 82	186 x 132	265 x 189
500	118 x 89	150 x 110	236 x 167	330 x 232
600	143 x 107	185 x 130	282 x 232	385 x 270



MÅTT



INKOPPLING



DOWNLOAD

DATABLAD

Beskrivning	Filformat	
Datablad	PDF	Hämta
Manual	PDF	Hämta

TEKNISK DATA

Bildfrekvens	60
--------------	----

Elektrisk anslutning	M12 4-polig D-kodad, M12 8-polig kontakt
Gränssnitt extern belysning	Strobe signal (24 V PNP N.O)
Indikering	4 LED
Interface	M12 4-polig Ethernet 10/100 Mbs
IP-klass	IP50
Material Kapsling	Aluminium
Material Lins	ABS-plast
Optik	6 mm integrerad
Ripple	1Vpp max med belysning
Spänning DC max	24 V
Spänning DC min	24 V
Spänningstolerans	10%
Strömförbrukning max	0,1 A
Temperaturområde från	-10 °C
Temperaturområde till	50 °C
Upplösning	640x480 (VGA)
Utgång	3xPNP, RS232
Utgångsström max	0,1 A

Step 1: Image Setup

The first step consists in connecting the sensor and configuring the image quality parameters. When the desired results are obtained, the user can memorize the image that will be used as a template during sensor functioning.

Step 2: Teach

The second step establishes the acceptance criteria to distinguish objects from wastes. One or more controls can be selected according to the task to carry-out.

Step 3: Run

The third step configures the sensor digital outputs, simulates sensor functioning on the PC to verify the controls chosen and activates the operating phase on the sensor using the PC only to control the diagnostics.

The professional model includes in the same software all the functionalities already available on Advanced and Identification versions. Moreover it features 5 new software tools: 3 locations and 2 controls.

Locations	Functioning
Barcode	Finds a barcode in the Region Of Interest and re-locates all the other inspection controls accordingly.
Datamatrix	Finds a datamatrix code in the Region Of Interest and re-locates all the other inspection controls accordingly.
360° Contour Match	Finds a reference template in the Region Of Interest and re-locates all the other inspection controls accordingly.
Controls	Functioning
360° Contour Counter	Counts how many times a reference contour is present in the Region Of Interest.
360° Defect Finder	Detects even smallest defects on a part.

M12 4-pole Ethernet

1 = white/orange = RX+
2 = white/green = TX+
3 = orange = RX-
4 = green = TX-

M12 8-pole (power supply and I/O)

OBJ and AOR models

1 = white = digital input 1
2 = brown = 24 VDC
3 = green = configurable output
4 = yellow = output 1
5 = grey = output 2
6 = pink = output 3
7 = blue = GND
8 = red = external trigger

ID and PRO models

1 = white = RS232 RX
2 = brown = 24 VDC
3 = green = configurable output
4 = yellow = output 1
5 = grey = output 2
6 = pink = RS232 TX
7 = blue = GND
8 = red = external trigger

